Figure 616.12.3.1 Work Zone "Speed Limit" Locations within the Advance Warning Area for Divided Roadways

Lane (2)

(T2)

TAPER LENGTH (ft.)

SPEED	SIGN SPACING (ft.)		TAPER LE
Normal Posted	Undivided (S)	Divided (S)	Shoulder (1) (T1)
(mph)	, ,	(-)	(* * )
0-35	200	200	This trusies
40-45	350	500	This typica sequencin Review ap spacing, ta TMA's, cha
50-55	500	1000	
60-70	1000	SA - 1000 SB - 1500 SC - 2640	

This typical application provides guidelines for the sequencing and location of the work zone speed limit signs. Review appropriate typical applications for signs, sign spacing, taper length, buffer length, channelizer spacing, TMA's, channelizers, flags, rumble strips, lights, AWRS, etc.

**OPTIONAL** 

**BUFFER** 

LENGTH (ft.)

(B)

CHANNELIZER SPACING (ft.)

Buffer/

Work Areas

**Tapers** 

